


User manual




WIRELESS CONTROLLER FOR XBOX ONE/XBOX ONE SERIES SIX/PS3/PC

Button Layout




How to Connect?

Wireless Controller For Xbox One/Xbox One Series SIX/PS3/PC





LED Indicators

The 4 leds will keep lighting in all modes



How to adjust vibration level

There are 4 levels of vibration (0%-30%-70%-100%)




How to set turbo Function

Enable/disable the manual and auto turbo speed function:

Step 1: Press the TURBO button and one of the function buttons simultaneously, to enable the manual turbo speed function.


Step 2: Repeat step 1, to enable the auto turbo speed function

Step 3: Repeat step 1 again, to disable the manual and auto turbo speed function of this button.




Change the Turbo Speed

There are 3 levels of turbo speed (5shots, 15shots, 25shots)



Audio Function



Routine maintenance

About Charging:

Recommend to use the 5V 1A charger to prevent damage to the controller circuit, and avoid high-power or PD fast charging chargers due to different charging protocols.

Dust Prevention:

To prevent joystick drifting caused by dust, use a storage bag or other protective measures to minimize dust impact on the inside of the game controller.

Firmware Update:

Check for the latest firmware updates on the [HTTPS://ELITEMODDINGGEAR.COM/DOWNLOAD](https://elitemoddinggear.com/download). If updates are available, follow the instructions provided to update the controller's firmware.

Ventilation Recommendation:

Store the controller in a dry environment to safeguard electronic components from potential damage due to humidity.

Protective Measures:

To safeguard vulnerable parts like joystick and joypad, use protective cases or films to minimize scratches and collisions during daily use.

Avoid Overuse:

Prevent overuse to extend battery life. Turn off the equipment when not in use.

Power Supply and Cable Inspection:

Regularly inspect the power cord and plug for integrity. Charge the controller periodically, as prolonged battery depletion can lead to battery damage.

Safety Performance Check:

Regularly examine the mechanical function of the product to ensure the proper operation of the device and other hardware.

Controller Q&A

Q: How long can the controller be used?

A: Under normal conditions, our controller can last for approximately 10 hours. Usage of features like vibration and Auto-fire affects battery consumption.

Q: How to Charge the Controller?

A: **Charging with Charging Cable:** Plug the provided charging cable into the controller's type-C port to charge it.

Q: What is the operating current and Voltage?

A: Working Voltage:4.5V-5.5V;Working Current:4.5V-5.5V;