




# WIRELESS GAMEPAD COMPATIBLE WITH PS3/PS4/PC

Wireless Gamepad Compatible With PS3/PS4/PC Operating Instructions

## Product Introduction

Wireless Game controller for PS4 with Touchpad / Six axis Sensor/Speaker / Headset jack is a new patent design compatible with PS4, PS4 Slim, PS4 Pro consoles. And PS3consoles via cable connect.  
PS4 and DualShock4 are registered brand by Sony.

### Product Photos:



## Product Introduction

Standard Buttons: PS, Share, Option, ↑, ↓, ←, →, ×, ○, □, △, L1, L2, L3, R1, R2, R3 , VRL, VRR, RESET.  
Software Support: Support with all versions of PS4.  
Connect Method: Connect via BT 4.2  
Effect Distance: ≥10m  
LED: RGB LED  
Charging Method: USB cable  
Battery: High Quality 600mA rechargeable Lithium Polymer Battery  
Speaker: With speaker separate output solution  
Mic/Headset: 3.5mm TRRS stereophonic hole, support mic and headset.  
Touchpad: With two side buttons function and touch function  
Vibration: Double Vibration  
Sensor: Motion sensor inside  
Compatible: Full compatible with PS4(same as original), PS3,IOS 13.0 above version, Android 10.0 above  
Buttons: Buttons with backlight

## Functions

Power ON  
Hold the PS button for 1 second to power on.  
  
Power OFF  
Hold the Home button for 1 second to power off when dis-connect to console.  
Hold the Home button for 10 seconds to power off when connect to console.

## Working Mode

PS4 / PS3 Console  
Basically Function: Fully support all functions in games, including digital/analog buttons, and LED color display function, vibration function.

Colorful LED Display:  
Searching Mode: White LED keeps blinking.  
Disconnect: LED turns off.  
Multi-users: User 1: Blue, User 2: Red, User3: Green, User 4: Pink.  
Sleeping Mode: Orange LED keeps lighting(When charging).  
Charging when standby: Orange LED keeps lighting, LED turns off after full charging.  
Charging when playing / connected: Blue LED keeps light.  
In game: LED color based on game's instruction.

Connect To PS4 Console:  
First time connect to the console or another PS4 system:  
Connect your wireless controller to your system using the USB cable, and then press the PS button.  
Your controller pairs with your system and turns on.  
PS:

1. You'll need to pair a controller when you use it for the first time and when you use your controller on another PS4 system. If you want to use two or more controllers, you must pair each controller.
2. After you've paired your controller, you can disconnect the USB cable and use your controller wirelessly.
3. It's possible to use up to four controllers at the same time. When you press the PS button, the light bar glows in your assigned color. The first controller to connect is blue, with subsequent controllers glowing red, green, and pink.

PS3 System  
Connect PS3 by wired Cable and play directly.  
Re-connect to console paired before:  
Power on console, and power on the game controller by press PS/Home button for 1 second, controller should connect to console automatically.

Wake Up game controller:  
Game controller turns to sleep mode after 30 seconds searching but cannot connect to console, or, with no use for 10mins under connect mode. Press PS button for 1 second to wake up game controller.


Connect the mono headset:  
For in-game voice chat, plug the mono headset into your controller's stereo headset jack.

Share your gameplay online  
Press the SHARE button and choose one of these options for sharing your gameplay online.(Follow the steps on screen)

PC System  
A. Connect PC by wired Cable,the gamepad default by X-input mode.and support PC steam games.

B.BT connection: Press Share button and hold it then press PS button , the light bar flash, and seacrh the BT via PC.

But Firstly need install the Driver " InputMapper", and keep open it when you need use the gamepad play PC X-input games.If not install the driver, the gamepad work on pc for D-input mode by default.



Note:Press Share+PS button and then search"Wireless Controller via BT searching interface

## IOS 13.0 / Android 10.0 Above version Devices

Under the gamepad power off status, press share button and hold it then press PS button simultaneously 3S to step into paring mode, the light bar shows white colour flash, search " DUALSHOCK 4 Wireless Controller" via IOS 13.0/ Android 10.0 Above version Devices, connect it, and the light bar keep pink colour long light, means it connects successful; if could not connect the device, the controller will goes to sleep mode in 60s;